

Before you start, read instructions carefully.

INSTRUCTIONS:

With your computer power switch turned off, insert the expander finger connector into your computer game port connector and let unit permanently sit behind your computer. Insert from 1 to 4 game cartridges into your expander. Never insert or remove a game cartridge while your computer power switch is turned on.

With the select switch, select the game you wish to play. The LED adjacent to the cartridge selected will turn on.

Set selector so that "80 COL" LED is on when you wish to use your computer in the 80 column mode.

Set selector so that "C64" LED is on when you wish to your computer in the 40 column mode.

Momentary press the reset button and wait for game to start. Repeat after a few seconds if necessary.

Your expander comes equipped with a 1/4 amp fuse to protect your computer. In the event that you lose power to your expander, replace fuse with the exact same type for your computer's continued protection.

MJB COMPUTER
PRODUCTS LTD.

Wishes you many hours of enjoyable use from your newly purchased expander.